

Tm:YAP & Tm:YAG



Jan Šulc
Helena Jelínková
Czech Technical University
Dep. of Physical Electronics
PRAGUE - CZECH REPUBLIC

Pavel Černý
Institute of Photonics
University of Strathclyde
GREAT BRITAIN

Karel Nejezchleb
Václav Škoda
CRYTUR, Ltd. TURNOV
Palackého 175, Turnov
CZECH REPUBLIC



Introduction

Tm doped crystals embrace several attractive features that nominate them as the material of choice for solid-state laser sources with emission wavelength tunable around $2 \mu\text{m}$. It was demonstrated that Tm:YAG laser can be tuned from $1.91 \mu\text{m}$ up to $2.15 \mu\text{m}$. Similarly, Tm:YAP laser has tuning range from $1.85 \mu\text{m}$ to $2.03 \mu\text{m}$. The quasi-three level system of Tm:doped crystals requires appropriate pumping geometry and good heat extraction from the active media. On the other hand, Tm doped



materials benefit from a long fluorescence lifetime, which is attractive for high-energy Q-switched operation. Also, the efficient cross-relaxation with neighbouring Tm^{3+} ions produces two excitation photons in upper laser level for one absorbed pump photon. This makes the laser very efficient with quantum efficiency approaching two and reduces thermal loading.

Tm:YAG and Tm:YAP found their application in medical lasers, radars and atmospheric sensing.



Tm:YAP

Properties of Tm:YAP depends on crystal orientation. Crystals cut along the „a” or „b” axis (P6mm space group) are mostly used.

	A-cut	B-cut
Absorption peak	794.8 nm	793.5 nm
Absorption cross section	$7 \times 10^{-21} \text{ cm}^2$	
Emission wavelength	1980 nm	1940 nm
Emission cross section	$5 \times 10^{-20} \text{ cm}^2$	
Excited state lifetime	4.4 ms (6 % Tm)	




Tm:YAG



Tm:YAG fluorescent lifetime is about two times longer than of thulium in YAP. The emission cross-section in Tm:YAG is lower than in Tm:YAP. Tm:YAG is optically isotropic material.

Absorption peak	785 nm
Absorption cross section	$7.5 \times 10^{-21} \text{ cm}^2$
Emission wavelength	2013 nm
Emission cross section	$2.2 \times 10^{-20} \text{ cm}^2$
Excited state lifetime	9.2 ms (6 % Tm)

Experimental results





Pumping laser radiation
Fibre coupled diode HLU30F400-790 (LIMO)
Emission: 793 nm (Tm:YAP), 785 nm (Tm:YAG)
Fibre: $D = 400 \mu\text{m}$, $NA = 0.22$

Focussing optics 1:1
Two achromatic doublets, $f = 75 \text{ mm}$, spot $380 \mu\text{m}$

Laser crystal - AR/AR for pump & laser
Length = 3 mm, Diameter = 3 mm
Tm:YAP: $c = 4 \text{ at.}\%$ Tm, Tm:YAG: $c = 6 \text{ at.}\%$ Tm

Laser resonator
Length = 30 or 40 mm
RM: $R = 100\%$ @ $1.8 - 2.1 \mu\text{m}$, $T_{\text{MAX}} @ 0.8 \mu\text{m}$, flat
OC: $R = 92$ or 97.5% @ $1.8 - 2.1 \mu\text{m}$, $r = 300 \text{ mm}$



Acknowledgment

Research supported by Czech Ministry of Industry and Trade, project No.: FI-IM2/129